Brought to you by Pro Gear & Transmission.

For parts or service call:

877-776-4600
407-872-1901

www.globaldifferentialsupply.com

906 W. Gore St. Orlando, FL 32805
parts@eprogear.com



Ground Studs (inside cab, driver side)



Ground Studs and splice pack (inside cab, passenger side, under heater unit)

Other ground junctions



Bus bar located inside Truck Electrical Center (center dash)



Driver terminal junction ground located inside LHS luggage compartment